AiM User Guide

EVO4S, SOLO 2/SOLO 2 DL kit for BMW S1000RR (from 2009)

Release 1.03



KIT





Models and years

This manual explains how to connect EVO4S and SOLO 2 DL to the bike engine control unit (ECU) and how to install AiM SOLO 2/SOLO 2 DL on the bike steering plate.

Compatible models are:

BMW S1000RR
 BMW S1000RR
 BMW S1000RR HP4
 2009 - 2014
 from 2015
 2013 - 2014

Warning: for these models/years AiM recommends not to remove the stock dash. Doing so will disable some of the bike functions or safety controls. AiM Tech srl will not be held responsible for any consequences that may result from the replacement of the original instrumentation cluster.



Kit content and part numbers

AiM developed a specific installation bracket for SOLO 2/SOLO 2 DL and a connection cable to the ECU for EVO4S/SOLO 2 DL.

2.1

Bracket for SOLO 2/SOLO 2 DL

Part number for **SOLO 2/SOLO 2 DL** installation bracket for **BMW S1000RR** – shown below – is: **X46KSBMWS1.**

Installation kit contains:

- 1 bracket (**1**)
- 1 allen screw with rounded head M8x45mm (2)
- 1 toothed washer (3)
- 2 allen screws with flat head M4x10mm (4)
- 1 rubber dowel (5)
- 1 spacer (**6**)






2.2 AiM cable for SOLO 2 DL

Part number for SOLO 2 DL connection cable for BMW S1000RR – shown below – is: V02569230.



Following image shows the cable constructive scheme:



Installation bracket and connection cable for SOLO 2 DL for BMW S1000RR can be bought together. Part number: **V0256923CS**.



2.3 AiM cable for EVO4S

Part number for EVO4S connection cable for BMW S1000RR – shown below – is: V02585140.



Following image shows the cable constructive scheme:

PIN layout Binder connector male 712 7c solder view	①	RED BLACK	CAN+	wire 6	PIN layout BMW connector
	② ————————————————————————————————————				front view
	4 nc				(0000)
	5 nc				5 6 7 8
	6 nc				
	7 nc				



EVO4S/SOLO 2 DL connection

To connect EVO4S/SOLO 2 DL to the BMW S1000RR ECU use the connector placed in different areas depending on models:

Originally it was the DWA (alarm) connector placed under the bike tail.

The image on the right shows the connector in detail.




Please note:

Models from 2020 have this connector placed on the right side of the bike, near the tank hinge, as shown in the following pictures.



Please note:

Models from 2024 have this connector placed on the tail of the bike under a cover, as shown in the following pictures.





Configuration with Race Studio 3

Before connecting EVO4S/SOLO 2 DL to the bike ECU, set all functions using the AiM software Race Studio 3. The parameters to set in the AiM device configuration section are ("ECU Stream" tab):

ECU Manufacturer: "BMW"

ECU Model:

- o "BIKE_S1000RR" for BMW S1000RR 2009 2014 and BMW S1000RR HP4 2013 2014
- o "BIKE_S1000RR_2015" for BMW S1000RR from 2015

After this first selection, enable/disable the 1200hm resistor and the "Silent" mode on CAN Bus as follows, according to the used device:

SOLO 2 DL
☐ Enable the CAN Bus 120 Ohm Resistor
Silent on CAN Bus



BMW protocols

Available channels change according to the selected protocol.

5.1

"BMW - BIKE_S1000RR" protocol

Received channels by EVO4S/SOLO 2 DL configured with "BMW – BIKE_S1000RR" protocol are:

CHANNEL NAME	FUNCTION
S1 RPM	RPM
S1 THROTTLE	Throttle
S1 GEAR	Gear Sensor
S1 NEUTRAL	Neutral sensor
S1 WATER TEMP	Engine cooling temperature
S1 SEL MAP	Selected map
S1 CHK ENGINE	Engine check
S1 SPEED F	Front wheel speed sensor
S1 HAND THRT	Manual Throttle
S1 SPEED R	Rear wheel speed sensor
S1 INTK AIR T	Intake air temperature
S1 YAW RATE	Yawing rate
S1 ROLL RATE	Rolling rate
S1 ACC LATER	Horizontal Accelerometer
S1 ACC VERTIC	Vertical Accelerometer
S1 TC INTERV	Traction Control Intervention
S1 TC OFF	Traction Control in OFF State (alarm)
S1 CLUTCH SW	Clutch Switch
S1 SIDE STAND	Side stand switch

User Guide



S1 BRK FR SW Front Brake switch

S1 BRK RR SW Rear Brake switch

S1 ACC LONGIT Longitudinal Accelerometer

S1 OIL PRESS SW Oil pressure switch

S1 EWS CTRL Immobilizer Control

S1 BRK FAIL Brake malfunction (Error)

S1 ABS OFF ABS in off State (alarm)

S1 MAP MENU Map selection menu

HP4 TC SEL Traction control selection

HP4 LAUNCH HP4 Launch control switch

HP4 POT R HP4 Rear potentiometer

HP4 POT F HP4 Front potentiometer

HP4 BANKING HP4 Banking angle

HP4 R SPEED HP4 Rear wheel Speed

HP4 BIKE SPD HP4 Bike speed

HP4 F SPEED HP4 Front wheel speed

HP4 ACC LON HP4 Longitudinal acceleration

Technical note: not all data channels outlined in the ECU template are validated for each manufacturer model or variant; some of the outlined channels are model and year specific, and therefore may not be applicable; channels labelled "HP4" are only available on **BMW S1000RR HP4 2013-2014** bikes.



5.2

"BMW - BIKE_S1000RR_2015" protocol

Received channels by EVO4S/SOLO 2 DL configured with "BMW – BIKE_S1000RR_2015" protocol are:

CHANNEL NAME	FUNCTION
--------------	-----------------

RPM RPM Gear Gear

SpeedF Front wheel speed
SpeedR Rear wheel speed

LongAcc Longitudinal accelerometer

LatAcc Lateral accelerometer

VertAcc Vertical accelerometer

RollRate Roll rate
YawRate Yaw rate

WaterTemp Water temperature
IntakeAirTemp Intake air temperature
BrakePressF Front brake pressure
BrakePressR Rear brake pressure

Banking Banking angle

TPS Throttle position sensor

HandTPS Handgrip throttle position sensor

MomTotRedu Total torque reduction

ASCTrqReduct Torque reduction by Automatic Stability Control

ASCTyreGrip Tyre grip by Automatic Stability Control

WheelMomAct Actual wheel torque

LaunchCtrl Launch control

TC Sel Traction control level selection

ABSActive ABS active status
LiftOff Anti-lift control

User Guide



DamperFmm Front dampers travel (mm)

DamperRmm Rear dampers travel in (mm)

InjFuelmL Fuel injection (millilitres)

OilLevelLow Low oil level switch (alarm)

ASCOn Automatic Stability Control ON status

MIL Malfunctioning indicator lamp (alarm)

RRebound Set Rear dampers rebound set

FRebound Set Front dampers rebound set

RBump Set Rear dampers bump set

FBump Set Front dampers bump set

Technical note: note all data channels outlined in the ECU template are validated for each manufacturer model or variant; some of the outlined channels are model and year specific, and therefore may not be applicable.